


## H-Nu 535 Visible Light Photoinitiator


<b>Name:</b> 2,4,5,7-Tetraiodo-3-hydroxy-6-fluorone	<b>Formula:</b> C <sub>13</sub> H <sub>3</sub> I <sub>4</sub> O <sub>3</sub>
<b>CAS #</b> 142189-38-6	<b>Synonyms:</b> TIHF, H-Nu 535

### General Information

- H-Nu Series of Fluorone dyes (H-Nu 470, 535 and 635) - photoinitiators with panchromatic absorbance throughout the UVA/visible spectrum (350-670 nm)
- **H-Nu 470, 535 and 635** - capable of curing a wide range of resins:  
Acrylates - free-radical mechanism  
Epoxides - cationic mechanism
- **H-Nu 535** - experimental photoinitiator, broad absorbance range of 450 nm to 550 nm ( $\lambda_{max}$ =535 nm)
- Non-toxic -- LD50 > 2500mg/kg (mouse)



H-Nu Photoinitiator Structures



Compound	W	X	Y	Z	$\epsilon$	$\lambda_{max}$ (nm)
H-Nu 470	H	H	H	OBu	30200	470
H-Nu 535	H	I	I	OH	91200	535
H-Nu 635	CN	I	I	OH	80000	635

$\epsilon$  is the molar extinction coefficient.  $\lambda_{max}$  (nm) is the peak maximum absorbance wavelength

### Benefits of Use

- High absorptivity, low concentrations are needed (0.01-0.15 wt%)
- Capable of significant depth of cure in free radical formulations, > 1 inch
- Time and energy savings when one-pass thick cure can replace thin multi-layered coatings
- Cure through UV opaque, pigmented, or colored substrates (e.g. Kapton)
- Initiator bleaching: from bright red to pale orange/no residual color
- Bleaching/color change indicator of exposure/cure with UV/visible light

## Physical Properties

Appearance	Red Solid
Molecular Weight	716 g/mol
Melting Point	>270 °C
Absorbance Maximum	535 nm
Molar Extinction Coefficient	91,200 (535 nm)

## Photoinitiator Usage Recommendations

### Complete dissolution of H-Nu Photoinitiators is required for best results:

- Dissolving H-Nu photoinitiators requires special care. Direct solubility of H-Nu 535 in resins can be difficult, predissolution of H-Nu photoinitiators in one of the following resins/solvents before adding resin is recommended
  - **Free Radical Only -- DMAA (N,N-Dimethylacrylamide)**
    - usage at 5-10 parts **DMAA** to 1 part **H-Nu 535**
  - **Cationic Only – GBL (γ-Butyrolactone)**
    - Usage at 5-10 parts **GBL** to 1 part **H-Nu 535**

**NOTE: DMAA** is an excellent solvent for **H-Nu 535**, but it **cannot be used in cationic resins** as it inhibits cure.

- The presence of any undissolved red particles is an indication of incomplete solubility. More heating or stirring may help with incorporation, or predissolution using **DMAA** or **GBL** as noted above is needed.
- Predissolving H-Nu 535 in the appropriate material may allow for easier addition and faster usage. If not predissolving **H-Nu 535**, stirring/heating (65C is ok) at least 3 to 4 hours before using the formulation to ensure maximum solubility is recommended.
- **H-Nu photoinitiator** systems and materials that contain them are light sensitive and should be kept in the dark or in light proof bottles when not in use.
- “Dimmed” light conditions or other form of light shielding for mixing and formulating when using H-Nu photoinitiators are recommended to prevent unwanted pre-polymerization.

## Photopolymerization Mechanisms

### Acrylate Cure (Free-radical)

- Coinitiators are required – amine acrylates (**AA**) at 5 - 10 wt.% are recommended
- H-Nu 254 iodonium salt is recommended for acceleration if needed (may cause instability)
- Recommended starting level of **H-Nu 535** - 0.05 - 0.15 wt.% based on total solids.
- Recommended starting concentrations:

Thin Cure (< 1 mm)

0.10 wt.% <b>H-Nu 535</b>	0.15 wt.% <b>H-Nu 254</b>	5 wt.% <b>Amine Acrylate (AA)</b>
---------------------------	---------------------------	-----------------------------------

Thick Cure (1 mm or greater)

0.05 wt.% <b>H-Nu 535</b>	0.15 wt.% <b>H-Nu 254</b>	5-10 wt% <b>AA</b>
0.05 wt.% <b>H-Nu 535</b>	N/A	5-10 wt.% <b>AA</b>

Optimization may be necessary for each individual application

SGL's experimental coinitiator **Borate V** improves cure response over typical amine coinitiators and can be purchased separately.

Photoinitiator package (when added to a model acrylate formulation)	Reactivity (1-highest, 5-lowest)	Stability and storage
<b>H-Nu 535 + H-Nu 254 + Borate V</b>	<b>1</b>	Needs refrigeration as it may polymerize in the dark at room T, can be used by mixing just prior to using.
<b>H-Nu 535 + Sulfonium Hexafluoroantimonate Salt + Borate V</b>	<b>2</b>	Needs refrigeration as it may polymerize in the dark at room T, can use by mixing just prior to using.
<b>H-Nu 535 + Borate V</b>	<b>3</b>	Stable at room T, refrigeration recommended when not in use to prolong shelf life.
<b>H-Nu 535 + H-Nu 254 + Amine</b>	<b>4</b>	May be unstable depending on resin used – use only as necessary
<b>H-Nu 535 + Amine</b>	<b>5</b>	Stable

- Typical formulations with Borate V:

0.05 - 0.1 wt.% <b>H-Nu 535</b>	N/A	0.50 wt.% <b>Borate V</b>
0.05 - 0.1 wt.% <b>H-Nu 535</b>	0.5 wt.% <b>H-Nu 254</b>	0.50 wt.% <b>Borate V</b>
0.05 - 0.1 wt.% <b>H-Nu 535</b>	1 wt.% <b>Sulfonium Salt</b>	0.50 wt.% <b>Borate V</b>

It is best to dissolve **Borate V** directly into **DMAA** (2 parts **DMAA** to 1 part **Borate V**) before adding the resin as **Borate V** is difficult to dissolve in some resin systems.

## Cationic Cure – Epoxides (including SU-8 photoresists\*)

- **H-Nu 535** requires **H-Nu 254 Iodonium salt** to achieve cure in epoxide resins
- **Accelerator AN-910-E** can greatly enhance cure speed and sensitivity and is recommended
- **H-Nu 535** concentration range spans from 0.05 to 0.2 wt.%, with a good starting point at 0.10 wt.% based on solids
- Recommended starting concentrations:  
**Standard:**  
0.10 wt.% H-Nu 535 + 2.5 wt.% H-Nu 254 Iodonium Salt  
  
**With Accelerator:**  
0.10 wt.% H-Nu 535 + 0.1 wt.% AN-910-E + 2.5 wt.% H-Nu 254
- Sulfonium salts will not work with **H-Nu 535** – you must use an iodonium salt
- Do not use **Amines** or **DMAA** solvent as they “poison” or quench the superacid formation, thus preventing cationic cure

\***SU-8 References:** Y. Lin, P.R. Hermann, and K.Darmawikarta, *Appl. Phys. Lett.* **86**, 7, 071117 (2005)  
J.H. Moon, S.-M. Yang, D.J. Pine, and W.-S. Chang, *Appl. Phys. Lett.* **85**, 18, 4184 (2004)  
D. Rodriguez Ponce, K Lozano, et al. *J. Polym. Sci.: Part B: Polym. Phys.* **48**, 1, 47 (2010)

## Formulation Examples

Free Radical Polymerization: All values are wt%

Thin film with LCD projector activation:

0.3% H-Nu 535

2% DMAA

2% DIDMA (free amine)

0.66% H-Nu 254

Photoinitiator package added to:

5% Fumed silica, thixotrope

95% Acrylate resin mix (consists of 15 parts CN964E75, 40 parts SR 454, 20 parts SR 306, 15 parts SR 399)

## Cationic Polymerization

### Structural adhesive

0.1% H-Nu 535  
0.1% AN-910-E  
2.5% H-Nu 254  
73% EPON 828 (bisphenol A diepoxide)  
24.3% Tone 305 (polyol)

### Flexible adhesive

0.1% H-Nu 535  
0.1% AN-910-E  
2.5% H-Nu 254  
97.3% Proprietary epoxide resin

## Product Safety and Handling

Please read MSDS information before handling any products described in this brochure.

### Disclaimer

All Spectra Group Limited, Inc. manufactured materials in this brochure are not intended for use in products which would be regulated by the Food and Drug Administration unless the finished product is tested in accordance with the FDA and other applicable safety testing requirements. Spectra Group Limited, Inc. is not able to recommend these materials for such uses and assumes no liability for any such use. Technical advice furnished by the seller shall not constitute a warranty or condition, statutory or otherwise, which is expressly disclaimed, all such advice being given and accepted is at the buyer's risk. Data and results that the user or buyer achieves may differ. Optimization, scale-up and product performance are the responsibility of the buyer or user.